

Left Side:1Pc	Right Side:1Pc	Door Frame:1Pc	Top Plate:1Pc	Bottom Plate:1Pc	
Face Panel: A:1Pc, B:2Pcs	Front Drawer Sealing: A:1Pc, B:2Pcs	Drawer Box: 3Pcs	Back Plate (left):1 Pc	Back Plate (Right):1 Pc	
Back Drawer Sealing:3Pcs	Movable Hanging Rod:12Pcs	Rail:3 Sets	Key:1 Set	M4*8 Screw:12PCS	Self-tapping Screw(5x12): 6Pcs
1	2	3			
Bend the drawer box as the drawing	Install the back drawer sealing	Fix the inner rail onto the left and right drawer panel			
4	5	6			
Install the face panel	Install the front drawer sealing	Fix the movable hanging rod onto the place where you need			
7	8	9			
Bolt the left side and left back with self-tapping screws(5x12)	Bolt the left back and right back by back connection	Bolt the right side and right back with self-tapping screws(5x12)			
10					
Install door frame properly.					
11	12	13			
Install the bottom plate as the drawings.	Install the top plate as the drawings.	Install the drawers. (Attention: put the blocking shaft of the lock at the top of anti-return rail)			
14					
Adjust each part till fit well, installation finished.					

左侧一件	右侧一件	背板一件	顶板一件	底板一件	
面板3件	面板内封3件	斗围3件	左背一件	右背一件	
斗堵3件	插杆12件	滑轨3套	钥匙一件	断尾丝12件	自攻丝7个
1	2	3			
如图: 把斗盒折弯成型。	如图: 把斗堵安装到位。	如图: 把轨道的内轨安装到斗侧上。			
4	5	6			
如图: 把面板安装上去。	如图: 把面板内封安装上去。	如图: 依次把活动杆安装到所需位置。			
7	8	9			
如图把左背和左侧用自攻丝链接	把右背和左侧用自攻丝链接	把右背和右侧链接			
10					
如图: 把门框安装上去。					
11	12	13			
如图把底板安装上去用自攻丝固定	把顶板安装上去用断尾丝固定	如图: 把安装好的抽屉依次安装上去。(注意 锁排要在防倒轨的上面)			
14					
进行各部位的微调, 安装完毕。					